

SICHERHEITSAUWEISUNGEN

WARUNG:

Beim Gebrauch sowie beim Auf- und Abbau besteht die Gefahr, dass Finger eingeklemmt werden – insbesondere beim Ein- und Ausklappen der Elemente. Seien Sie daher besonders vorsichtig. Vergewissern Sie sich, dass das Produkt sicher und stabil steht und alle Verriegelungen vollständig eingerastet sind, bevor Sie sich auf die Bänke setzen oder Gegenstände auf den Tisch stellen. Beachten Sie die Wetterbedingungen. Obwohl das Set wetterbeständig ist, kann eine anhaltende Belastung durch extreme Witterung die Lebensdauer verkürzen. Lagern Sie das Set bei ungünstigen Wetterverhältnissen im Innenbereich. Pflegen Sie das Produkt regelmäßig entsprechend den Pflegehinweisen.

WARTUNG UND PFLEGE

Um die Langlebigkeit und das Erscheinungsbild Ihres Biergartensets zu erhalten, beachten Sie bitte folgende Empfehlungen:

Reinigung: Reinigen Sie die Oberflächen mit einem feuchten Tuch. Bei stärkerer Verschmutzung verwenden Sie eine milde Seifenlösung und trocknen anschließend gründlich nach. Vermeiden Sie den Einsatz von Scheuermitteln, aggressiven Reinigungsmitteln oder lösungsmittelhaltige Reiniger (z.B. Bleichmittel)

Lagerung: Wenn das Set nicht in Gebrauch ist – besonders in der Nebensaison oder bei schlechtem Wetter – lagern Sie es zusammengeklappt an einem trockenen, geschützten Ort, um Schäden durch Feuchtigkeit oder extreme Temperaturen zu verhindern.

Regelmäßige Kontrolle: Überprüfen Sie in regelmäßigen Abständen alle Schrauben, Bolzen und Verriegelungen, um sicherzustellen, dass sie fest angezogen und funktionsfähig sind. Ziehen Sie lockere Verbindungen gegebenenfalls nach.

Holzpflege: Die Tannenholzoberflächen sind schützend lackiert. Sollte der Lack mit der Zeit Abnutzungsspuren zeigen, tragen Sie eine geeignete, transparente Außenholz-Lackierung erneut auf, um den Schutz zu bewahren.

HOLZPFLEGEHINWEISE:

Produkte aus Hartholz sollten mindestens zweimal jährlich geölt werden. Vor dem Nachölen das Holz mit feinem Schleifpapier leicht anschleifen und reinigen. Anschließend gemäß der Anleitung Ihres Pflegeöls behandeln.

FEHLERBEHEBUNG

Nachfolgend finden Sie einige häufige Probleme und entsprechende Lösungen:

Instabilität: Sollte der Tisch oder die Bänke wackeln, prüfen Sie, ob alle Beine vollständig ausgeklappt und die Verriegelungen richtig eingerastet sind. Achten Sie außerdem darauf, dass das Set auf einer ebenen Fläche steht.

Schwierigkeiten beim Zusammen- oder Auseinanderklappen: Vergewissern Sie sich, dass keine Fremdkörper die Scharniere oder Klappmechanismen blockieren. Bei schwergängigen Teilen kann eine geringe Menge Silikon Spray Abhilfe schaffen.

Oberflächenschäden: Kleinere Kratzer oder Dellen im Holz lassen sich mit Holzreparatursets oder passender Außenholzfarbe bzw. Lack ausbessern.

SAFETY INSTRUCTIONS

WARNING:

During use as well as during assembly and disassembly, there is a risk of fingers getting trapped – especially when folding or unfolding the parts. Please exercise caution. Ensure that the product is placed securely and stably, and that all locking mechanisms are fully engaged before sitting on the benches or placing objects on the table. Be mindful of weather conditions. Although the set is weather-resistant, prolonged exposure to extreme weather may shorten its lifespan. Store the set indoors during adverse weather conditions. Maintain the product regularly in accordance with the care instructions.

MAINTENANCE AND CARE

To preserve the longevity and appearance of your beer garden set, please follow these recommendations:

Cleaning: Clean the surfaces with a damp cloth. In case of heavier soiling, use a mild soap solution and then dry thoroughly. Avoid using scouring agents, aggressive cleaning products, or solvent-based cleaners (e.g. bleach).

Storage: When not in use – especially during the off-season or in bad weather – store the set folded in a dry, sheltered place to prevent damage from moisture or extreme temperatures.

Regular Inspection: Check all screws, bolts, and locking mechanisms periodically to ensure they are tight and functioning properly. Tighten any loose fittings as needed.

Wood Care: The fir wood surfaces are coated with a protective varnish. If the coating shows signs of wear over time, apply a suitable clear exterior wood varnish to maintain protection.

WOOD CARE INSTRUCTIONS:

Products made of hardwood should be oiled at least twice a year. Before re-oiling, lightly sand and clean the wood with fine sandpaper. Then treat according to the instructions of your chosen care oil.

TROUBLESHOOTING

Below are some common issues and their corresponding solutions:

Instability: If the table or benches wobble, make sure all legs are fully extended and the locking mechanisms are properly engaged. Also ensure that the set is placed on a level surface.

Difficulty Folding or Unfolding: Check that no foreign objects are obstructing the hinges or folding mechanisms. If parts are stiff, apply a small amount of silicone spray to the moving components.

Surface Damage: Minor scratches or dents in the wood can be repaired using wood repair kits or appropriate exterior wood paint or varnish.