


Montage- und Betriebsanleitung

Art.-Nr.: 13690

Pelletfackel Apollo



Bevor Sie dieses Gerät in Betrieb nehmen, lesen Sie bitte diese Montage- und Gebrauchsanleitung sorgfältig durch.

Bewahren Sie diese Gebrauchsanleitung zum späteren Nachschlagen gut auf.

1. Inhaltsverzeichnis

1. Inhaltsverzeichnis	2
2. Sicherheitshinweise.....	2
3. Aufstellhinweise.....	3
4. Bestimmungsgemäße Verwendung	3
5. Umwelt und Entsorgungsmaßnahmen.....	4
6. Montage-Vorbereitung.....	4
7. Stückliste	5
8. Montage	6
9. Brennstoff.....	9
10. Hinweise zum Anzünden des Gerätes.....	9
11. Reinigung und Pflege	9
12. Lagerung:.....	9
13. Entsorgung	10
14. Index.....	12
15. Warnings.....	12
16. Safety	12
17. Shipping and Stocking	13
18. Installation Instructions.....	14
19. Part List.....	16
20. Assembly	17
21. User Guide.....	19
22. Start.....	20
23. Cleaning and Maintenance	21

2. Sicherheitshinweise

Bitte beachten Sie folgende Symbol-Hinweise:



Warnhinweise!



Beachten!

Allgemeine Sicherheitshinweise:



Achtung! Diese Pelletfackel, insbesondere das Glasrohr, wird sehr heiß und darf während des Betriebes nicht bewegt oder berührt werden! Nicht in geschlossenen Räumen oder in der Nähe von brennbaren Gegenständen benutzen!

Achtung! Zum Anzünden oder Wiederanzünden keinen Spiritus oder Benzin verwenden!
Nur Anzündhilfen entsprechend DIN-EN1860-3 aus dem Handel verwenden!

Achtung! Kinder und Haustiere fernhalten

- Tragen Sie beim Befeuern Grillhandschuhe.
- Lassen Sie die Pelletfackel vor dem Reinigen völlig abkühlen! Es besteht ansonsten Verbrennungsgefahr. Tragen Sie zur Sicherheit trotzdem feuerfeste Handschuhe.



- Die Pelletfackel muss während des Betriebes auf stabilem, ebenem und nicht brennbarem Boden stehen!
- Verwenden Sie niemals Wasser zum Löschen des Feuers!
- Das Gerät nicht auf überdachten Flächen oder in geschlossenen Räumen benutzen!
- Lassen Sie die heiße Pelletfackel nicht unbeaufsichtigt!
- Die Pelletfackel nicht in die Nähe von Eingängen und viel begangenen Gebieten aufstellen!
- Keine Kleidung mit weiten Ärmeln tragen!
- Lassen Sie Kinder nicht mit Verpackungsfolien spielen! Erstickungsgefahr!
- Verwenden Sie keine Farblösemittel oder Verdünnungen, um das Gerät zu reinigen!
- Nehmen Sie die Pelletfackel nicht bei Unwetter oder Regen in Betrieb! Dies könnte zu Beschädigung des Glasrohrs führen!
- Benutzen Sie die Fackel nicht, wenn das Glasrohr beschädigt ist!
- Berühren Sie das Gerät während des Betriebs nicht! Verbrennungsgefahr!

3. Aufstellhinweise

Die Mindestabstände von 120cm zur Fackel sind zu gewährleisten.

Die Pelletfackel darf nur im Außenbereich oder in gut belüfteten Räumen betrieben werden. Bei einem gut belüfteten Raum müssen mindestens 25% der Umschließungsfläche offen sein.

Die Umschließungsfläche ist die Summe aller Wandflächen.



4. Bestimmungsgemäße Verwendung

Die Pelletfackel darf ausschließlich zur Befeuerung mit Holzpellets (siehe Punkt 8) eingesetzt werden. Es müssen dabei alle Vorgaben dieser Anleitung eingehalten werden.

Nur für den privaten Gebrauch!

Die Verwendung von Pelletfackeln darf nicht zum Zweck der Abfallbeseitigung erfolgen.

Verwenden Sie dieses Gerät nur, wie in dieser Bedienungsanleitung beschrieben.

Jede andere Benutzung gilt als nicht bestimmungsgemäß und kann zu Sachschäden oder Personenschäden führen.

Der Hersteller übernimmt keine Haftung für Schäden die durch einen nicht bestimmungsgemäßen Gebrauch des Produktes verursacht worden sind!

5. Umwelt und Entsorgungsmaßnahmen

- Achten Sie auf Sauberkeit und Sicherheit beim Umgang mit der Pelletfackel und bei der Entsorgung von Reststoffen.
- Den Restabfall grundsätzlich nur in dafür vorgesehenen Gefäßen aus Metall bzw. nichtbrennbaren Materialien entsorgen.

6. Montage-Vorbereitung


Aufbauzeit

ca. 20min.



- Lesen Sie die Montageanleitung sorgfältig durch und folgen Sie den Montageschritten.
- Nehmen Sie sich ausreichend Zeit für den Zusammenbau.
- Schaffen Sie sich ein Arbeitsflächen von ca. 2 – 3 m².
- Entnehmen Sie die Teile aus der Verpackung und prüfen vor der Montage die Vollständigkeit der einzelnen Teile.
- Es wurde jede Anstrengung in der Fertigungsstätte unternommen, um scharfe Kanten an diesem Gerät zu vermeiden. Gehen Sie mit den Einzelteilen vorsichtig um, damit Unfälle bzw. Verletzungen während des Aufbaues und der Inbetriebnahme vermieden werden.
- Arbeiten Sie gegeben falls zu zweit.
- Legen Sie sich das benötigte Werkzeug in Reichweite.
- Ziehen Sie erst nach der kompletten Montage des Gerätes alle Schraubverbindungen fest an.
- Sollte trotz Kontrolle im Werk etwas fehlen, kontaktieren Sie unseren Kundendienst (letzte Seite).
- Kleine technische Änderungen des Gerätes, insbesondere in Bezug auf den Inhalt des Befestigungsmaterials müssen wir uns vorbehalten.
- Einige Teile sind werkstechnisch bereits mit anderen Teilen **vormontiert**.

7. Stückliste



Bitte beachten Sie, dass wir uns kleine werkstechnische Änderungen bezüglich des Befestigungsmaterials vorbehalten müssen.

8. Montage

Schritt 1

Halten Sie die beiden Fußhälften aneinander und montieren Sie die Schrauben mit der Verbindungsplatte (Schrauben noch nicht festziehen). Stellen Sie den Fuß jetzt auf eine gerade Fläche, richten Sie die Fußhälften zueinander aus und ziehen Sie jetzt die Schrauben an.

Benötigte Teile

Schraube M5x10



8x

Scheibe




4x

Verbindungsplatte



2x



Schritt 2


Montieren Sie die Halterung am Brennkörper.

Benötigte Teile

Schraube M5x10




4x




Schritt 3

Setzen Sie das Glasrohr 2 ein. Das funktioniert am besten mit einer Drehbewegung.




Schritt 4

Montieren Sie den Deckel und den Aschebehälter



Schritt 5

Setzen Sie das Glasrohr 1 ein.



Die Pelletfackel ist nun betriebsbereit!

**Vor Inbetriebnahme des Gerätes die Sicherheitshinweise
und Hinweise zum Anzünden der Fackel sorgfältig lesen!**



Bitte beachten Sie, dass wir uns kleine werkstechnische Änderungen
bezüglich des Befestigungsmaterials vorbehalten müssen.

9. Brennstoff

Die Pelletfackel wird mit Holzpellets mit folgenden Eigenschaften betrieben:

- Entsprechend den Normen EN-ISO 17828 / EN 15210-1
- ENplusA1-zertifiziert
- Länge: 15-40mm
- Durchmesser: Ø6mm
- Feuchtigkeit: max 10%
- Dichte: 600-750kg/m³
- Mindestheizwert: 4,6kWh/kg
- Rohmaterial: nur natürliches Holz – vorzugsweise 100% Weichholz

10. Hinweise zum Anzünden des Gerätes



1. Befüllen Sie das Pelletrohr mit den unter 8. beschriebenen Pellets.
2. Nehmen Sie das Glasrohr 1 ab.
3. Legen Sie einen Grillanzünder in den Brennraum und entzünden Sie diesen mit einem langen Streichholz oder einem Stabfeuerzeug.
4. Warten Sie, bis sich eine Flamme gebildet hat und die Pellets entzündet sind
5. Setzen Sie das Glasrohr auf. Benutzen Sie hierfür feuerfeste Handschuhe.
6. Die Flamme wird nun Stück für Stück wachsen.

- Solange Sie durch das Pelletrohr noch keine Glut sehen können, können Sie jederzeit Pellets nachfüllen.
- Falls Sie durch das Pelletrohr bereits Glut sehen können, sollte Sie keine Pellets mehr nachfüllen, da Sie das Feuer dadurch ersticken könnten.
- Sollte das Feuer erlöschen, lassen Sie die Pelletfackel vor dem Wiederentzünden vollständig auskühlen.

11. Reinigung und Pflege

Zur Erhaltung des schönen Aussehens ist natürlich eine gelegentliche Reinigung erforderlich. Verwenden Sie kein Scheuermittel.

- Benutzen Sie niemals Wasser um die heiße Pelletfackel abzukühlen.
- Für die normale Reinigung reicht ein Spültuch und Wasser mit einem handelsüblichen Spülmittel.

12. Lagerung:

- Schützen Sie das Gerät vor Nässe und Unwetter.
- Decken Sie das Gerät gegeben falls nach völliger Abkühlung mit einer dafür geeigneten Hülle ab.

13. Entsorgung



Nach einer Außerbetriebsetzung des Geräts ist dieses umweltfreundlich zu entsorgen.

Befolgen Sie dabei die lokalen Vorschriften bei der Entsorgung.


Das Gerät besteht zum Großteil aus Edelstahl und aus unterschiedlichen Anteilen von anderen Materialien.

- Metallische Werkstoffe gelten allgemein als uneingeschränkt recyclingfähig. Trennen Sie die Bauteile zur Verwertung z. B. nach folgenden Kategorien:
 - Stahl und Eisen, Aluminium, Buntmetall
 - Kunststoffe
 - Glas
- Für die Verpackungsmaterialien nehmen Sie bei Bedarf Kontakt mit einem Entsorgungsfachbetrieb auf.

Instruction Manual

Model: 13690

Pellet Heater Apollo



WARNING: FOR OUTDOOR USE ONLY OR IN AMPLY VENTILATED AREAS!

PLEASE KEEP THE MANUAL FOR FUTURE REFERENCE!

Please take some time to read this manual carefully before you use it for the first time. In this way you can make the best use of your appliance in conditions of safety and efficiency

14. Index

14. Index.....	12
15. Warnings.....	12
16. Safety	12
17. Shipping and Stocking	13
18. Installation Instructions.....	14
19. Part List.....	16
20. Assembly	17
21. User Guide.....	19
22. Start.....	20
23. Cleaning and Maintenance	21

15. Warnings

Read the instructions carefully and follow the prompts. This manual is manufactured by the manufacturer and is a large part of the product. Compliance with the instructions contained in this note results in safe, efficient operation of people and businesses, and ensures long-term functional availability and long life. The manufacturer is not liable for any compensation at the time of use.

16. Safety

The appliance has been designed to minimize the risks for the user and maintenance personnel. During the project, it was not technically possible to completely eliminate the causes of risk, therefore it is absolutely necessary to comply with the following instructions.



The use of the appliance is prohibited to children and unassisted disabled people.

It is forbidden to tamper with the safety or adjustment devices and any other modification without the manufacturer's authorization.

The use of the appliance as an incinerator or in any case the use in a different way for which it was built is prohibited.

It is forbidden to place rags or clothes to be dried on the appliance, any drying racks must be placed at a minimum distance of 1.2 meters from the appliance in order to avoid fire hazards.

It is forbidden to operate the appliance if the glass of the combustion chamber is broken.



It is forbidden to clean the glass and all hot parts while the appliance is in operation.

It is forbidden to touch the appliance while it is running or in any case when it is not completely cooled as some parts (handle, glass, etc.) could cause burns. If necessary, use protective clothing (example: gloves, etc.). It is forbidden to put flammable materials near the appliance (example: bags of pellets, flammable liquids, etc.).



Children must not play with the appliance even if it is turned off. Cleaning and maintenance is intended to be carried out by the user or by qualified personnel.



WARNING

Do not use the appliance under rain, the glass protections may break when they suddenly encounter water. Always turn off the appliance while it rains. Do not spray any liquid on the glass while the appliance is running. The glass is extremely hot during operation, do not try to touch it and keep children away from the appliance. Always make sure that the equipment is in a stable position. The glass protections could break if the appliance falls to the ground. Do not use the appliance if the glass is broken or damaged.



CAUTION

Some parts of this product can become very hot and cause burns. Particular attention must be paid where children and vulnerable people are present.

During and immediately after operation, the appliance is extremely hot.

NEVER touch the appliance during or immediately after operation.

NEVER move the appliance during this time.

17. Shipping and Stocking



The body of the appliance must always be moved in a vertical position. Particular attention must be paid to ensuring that the glass and all delicate parts are preserved from mechanical impacts that compromise its integrity and correct functioning.

The appliance and any accessories such as steel, glass or stone cladding must be stored in closed and humidity-free rooms. Do not stack the appliances one on top of the other. Handle with care the boxes containing the appliances.

It is not recommended to keep the product in stock for excessively long periods.

18. Installation Instructions

The installation and assembly of the appliance must be carried out carefully following the instructions and in full compliance with the state and local reference standards . An installation that does not comply with the provisions of the regulations can cause damage to people, animals or things. In this case The manufacturer declares itself relieved of any responsibility.



ATTENTION: if the indications given in this booklet are not respected and / or if the installation is not in a workmanlike manner and / or if the provisions in force on the matter are not respected, this can occur dangerous conditions both for things and for people.



Pellet heater is an open hearth combustion appliance intended exclusively for outdoor use or in partially closed rooms such as porches, pergolas. The positioning of the appliance must take place on a leveled surface with adequate load capacity in relation to the weight of the appliance. If necessary, redistribute the weight evenly by placing an adequately sized fireproof platform between the floor and the appliance.



ATTENTION: the appliance must be installed perfectly perpendicular to the ground.

The appliance has been designed to work with favorable climatic conditions, in case of particularly adverse conditions (strong wind, intense rain, snow) it is not recommended to use the appliance.



Installation of the appliance in unsuitable rooms with insufficient ventilation (where the correct evacuation of combustion products is not guaranteed) is not allowed. It is forbidden to place the device in environments with an explosive atmosphere.





The combustion products generated by the appliance must be evacuated directly into the atmosphere, these are not very visible but very hot and therefore can cause burns.

It is absolutely forbidden to obstruct the smoke outlets of the appliance with protective nets or anything else since they could cause serious malfunctions of the appliance.

It is absolutely forbidden to connect the end of the appliance to pipes or flues to convey combustion products elsewhere.


Important Safety Rules

For use outdoors or in amply ventilated areas.
 An amply ventilated area must have a minimum of 25% of the surface area open.
 The surface area is the sum of the walls surface.
 The use of this appliance in enclosed areas can be dangerous and is **PROHIBITED**.
 Children and adults should be aware of the high operating temperatures of areas above the post when operating this appliance. Children should be carefully supervised when in the vicinity of the appliance.
NEVER hang anything, including clothes or any other flammable items, on this appliance.
DO NOT operate this appliance unless it is fully assembled with its reflector in place.
 Respect the minimum clearances from combustible materials.



The installation distances must be respected for safety and fire prevention.
 If the floor is made of flammable material, for example: (wood, carpet, rubber, plastic), it is mandatory to provide for the use of adequately sized floorboards (sheet metal, glass). It is prohibited to place flammable materials near the appliance (example: bags of pellets, flammable liquids, etc.).

19. Part List



20. Assembly

Instruction before assembly

Required Tools: Adjustable Spanners / Wrenches

Before assembly, make sure all packing material and any transit protection must be moved. Small deviations in equipment may occur.



Please remove out all glass parts slowly and carefully.

Caution: Do not touch the appliance surface while it is working!



Step 1

First twist the connecting part of the two support legs (do not tighten first), keep the two support legs on the table or ground of a relatively consistent height, alignment them together, and then lock it.

Installed on the main parts.
Keep it level and lock.

Hardware Used

Bolt M5X10		X8
Elastic pad		X4
Connector		X2



Step 2


Install the fixing rod to the rocket body (icon) and tighten with screws.

Hardware Used

Bolt M5X10		X4
------------	--	----


Step 3

Install the glass tube 2 ,
it is better to install it in a
rotating way.




Step 4

Insert the dust box
and cover into the
positions.



Step 5

Insert glass tube 1.



21. User Guide



We remind you that the use of the appliance by children is prohibited. The external parts of the appliance, when it is turned on, are very hot, especially the glass and the door; therefore provide for appropriate measures or protections against accidental contact and fire hazards.

The Pellet

The fuel used is called pellet, which is pressed wood sawdust granules. By using only quality pellets, an almost neutral environmental impact in terms of CO₂ is obtained, a high efficiency and less ash accumulation inside the appliance.

Below are the reference parameters of a good quality pellet:

- **Approved according to NEN-EN-ISO 17828/ NEN-EN 15210-1**
- **Just use certified pellets – ENplusA1**
- Length: 15- 40 mm
- Diameter: 6 mm
- Maximum moisture content: 10%
- Density: 600 – 750 kg/m³
- Minimum calorific value: 4,6 kWh / Kg
- Raw material: only natural wood - preferably 100% softwood



The use of the appliance as an incinerator or in any case the use in a different way for which it was built is prohibited.

It is forbidden to use other types of fuel for powering or switching on the appliance.

The use of any pellet other than that indicated is prohibited. The use of fuel that does not comply with the above specifications, in addition to immediately voiding the appliance warranty, can create dangerous situations.

Preliminary Check up



All preliminary checks must be performed at the first ignition or after a long period of inactivity.

Check that the positioning of the appliance respects the safety distances.

Check that there are no flammable materials near the appliance. For safety distances see Paragraph 18



In case of an ignition after a long period of inactivity, all parts of the brazier, the glass and the fan area, must have previously been inspected and cleaned of ash and dust.



Check that there are no flammable materials inside the combustion chamber (documentation, cables, paper, etc.)

22. Start

After unpacking the appliance, prepare all accessories nearby.

Before starting the ignition phase it is advisable to carry out preliminary checks:

- Check that the positioning of the appliance respects the safety distances.
- Check that the appliance has no obstructions on the top near the smoke outlet.
- Check that the appliance is positioned flat, stable and perfectly vertical



Once the device is turned on, the pellet load must be completely burned according to the cycle and the process must not be interrupted.

NOTE

During the first ignition, the appliance will exhale, for a few hours, the smell of paint.

Recall that these odors are annoying but are not harmful.

After each operating cycle, it is normal for a minimum residual amount of ash to remain in the tank, which must be removed before starting the next cycle.

23. Cleaning and Maintenance

Intro

Since your appliance is pellet-powered, it requires regular general checking and cleaning. Regular maintenance ensures smooth operation and optimal performance. The user must periodically take care of cleaning the appliance as indicated in this manual.



Since your appliance is pellet-powered, it requires regular general checking and cleaning. Regular maintenance ensures smooth operation and optimal performance.



The user must periodically take care of cleaning the appliance as indicated in this manual.



For external cleaning do not use aggressive or abrasive products.

Cleaning and Maintenance



Unless otherwise specified, the operations listed below are mandatory and cannot be postponed beyond the time indicated.

ATTENTION: if an ash vacuum cleaner is used, make sure that there are no embers still lit and that the ash is cold.

Clean the glass when deemed appropriate, using a cotton cloth or kitchen paper with a specific glass cleaner for stoves and fireplaces that you will find from your dealer.